

TOWER®

BUILT FOR BETTER SINCE 1912

Instructions & Guarantee Registration

PLEASE READ CAREFULLY



60 Litre
Ozone Sensor Bin

60 Litre Ozone Sensor Bin

1. Sensor Bin Lid

2. Lid base/battery compartment/
filter compartment

3. Open/Close button/
Ozone Filtration/
On/Off button

5. Retainer ring

4. Bin body

6. Base



STRUCTURE OF THE SENSOR BIN

- | | |
|---|-------------------|
| 1. Sensor bin lid | 4. Bin body |
| 2. Battery compartment / filter compartment
(inside of unit) | 5. Retaining ring |
| 3. Open/Close button / Ozone Filtration On/Off
button | 6. Feet |

Thank you...

... for purchasing a Tower 60 Litre Ozone Sensor Bin. We hope you have years of hassle-free cleanliness with your new purchase.

IMPORTANT SAFETY INFORMATION

Please read these notes carefully **BEFORE** using your Tower product.

- Safety First! To avoid suffocation, keep wrappers away from babies and children.

BEFORE FIRST USE

Read all instructions and safety information carefully before first use. Please retain this information for future reference.

1. Remove the product from the box.
2. Remove any packaging from the product.
3. Assemble the product as detailed in the relevant section below.
4. Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.
5. Dispose of the packaging in a responsible manner.

NOTE: Save these instructions for future reference. This product is intended for household use.

OPERATING INSTRUCTIONS

Note: If required, refer to the parts diagram on page 2

Installing the Batteries

To use the sensor bin, start by inserting 6 x AA batteries into the corresponding compartment inside the sensor bin lid. To do this, carry out the following steps:

1. Locate the battery compartment and remove the cover flap.
2. Remove the battery casing from the battery compartment and insert 3 x AA batteries (not included) on each side of the casing (3 at the top and 3 at the bottom) for a total of 6 x AA batteries.
3. Place the battery casing back into the battery compartment. Ensure the contacts on the casing line up with the contacts inside the compartment, otherwise the unit will not work.
4. If the casing has been inserted correctly, the lights on the underside of the bin lid and the unit's LED control panel will briefly light up to show it is on. If this does not occur, take out the battery casing and re-insert it into the battery compartment, ensuring the contacts line up.
5. Once the batteries have been correctly installed, replace the cover flap onto the battery compartment, ensuring it is secured into place.
6. The unit is now ready for normal use.

Installing the Carbon Filter

To use the sensor bin, start by installing the filter. To do this, carry out the following steps:

1. Turn the sensor bin lid upside down and locate the filter compartment on the underside of the lid.
2. Open the filter compartment lid by holding one of the sides and pulling it firmly up and away from the main body of the unit, as shown in the image below. DO NOT attempt to pull the filter cover out by holding onto the top or bottom, as this might damage the unit.



3. Once the filter compartment is open, place one of the included carbon filters inside it and replace the cover, ensuring it clicks into place.
4. The carbon filter is now ready for normal use.

Note: For optimal performance, we recommend replacing the Ozone Filter Fresh carbon filter every three months.

OPERATING INSTRUCTIONS

Installing the Retainer Ring



1. Place the bin liner in the centre of the retainer ring. Fold the top of the bag over the edge of the retainer ring, then tuck the edges back into the bin.
2. With the retainer ring and bag firmly secured, place the lid back onto the sensor bin. The unit is now ready for normal use.

Using the Sensor Bin

1. Once the batteries and filter have been correctly inserted, press and hold the On/Off button for five seconds to activate the automatic sensor function, as shown in the picture below. The five blue LED indicators on the unit's control panel will progressively illuminate from right to left to show this function has been activated, as shown in the image below.



Note: Keep the button pressed until all five indicators are illuminated.

Note: Once the sensor function is activated, the five blue LEDs will progressively illuminate every time the sensor lid is activated, and progressively de-illuminate as it closes.

2. Press and hold this button again while the bin is in operation to deactivate the automatic sensor function. The five blue LED indicators on the unit's control panel will progressively de-illuminate from left to right to show this function has been activated.

The Ozone Filter Fresh Function

This unit is equipped with Ozone Filter Fresh technology, which helps reduce bacteria and odours.

Press and hold the Filter button to activate the Ozone Filter Fresh technology. The five blue LED indicators on the unit's control panel will progressively illuminate from left to right to show this function has been activated. (The sensor bin is now in the Ozone 60 second filter fresh cycle)

Note: Keep the button pressed until all five indicators are illuminated.

BATTERIES:

The batteries can last 3-6 months based on the bin lid opening and closing 20 times a day.

High alkaline batteries can last up to 2 years on standby only.

CARE & USE

Do Not apply any external power to the lid when it is in use.

Do not press on the lid when it is opening.

Do not manually open the lid as it may damage it.

ONLY use type AA batteries and remove them once they have run out to prevent leakage. If the bin fails to operate normally, it may mean the batteries are running low, or need replacing. Please avoid mixing brands, or using old batteries.

Avoid staying in sensing mode for an unduly long time to prolong the life of the motor and batteries.

Do Not use water to rinse bin lid or battery compartment. You can wipe it with a slightly damp cleaning cloth when the power is off.

DO NOT IMMERSE IN WATER.

Do not use harsh abrasive detergents or scouring pads to clean the main plastic body.

Avoid using the bin in a moist or steamy environment.

Keep the inductive window away from direct sunlight or lamplight.

Do not place the bin close to high frequency electronic products, i.e.: microwave ovens, energy saving lamps, or remote controls, etc.

Avoid placing the bin in a contained space and ensure that any obstacles don't block the inductive window within a 2 metre distance.

GUARANTEE

This product is guaranteed for 12 months from the date of original purchase.

If any defect arises due to faulty materials or workmanship, the faulty products must be returned to the place of purchase.

Refund or replacement is at the discretion of the retailer.

The standard one year guarantee is only extended to the maximum available for each particular product upon registration of the product within 28 days of purchase.

If you do not register the product with us within the 28 day period, your product is guaranteed for 1 year only.

VALIDATING YOUR 5 YEAR GUARANTEE

To validate your extended warranty, please visit:

www.towerhousewares.co.uk

and register with us online.

Alternatively, call our customer registration line:

+44 (0)844 984 0055

Please note that length of extended warranty offered is dependent on product type and that each qualifying product needs to be registered individually in order to extend its warranty past the standard 1 year.

TERMS AND CONDITIONS

- The product must be returned to the retailer with proof of purchase.
- The product must be installed and used in accordance with the instructions contained in this booklet.
- It must be used only for domestic purposes.
- It does not cover wear and tear, damage, misuse or consumable parts.
- RKW has limited liability for incidental, or consequential loss or damage.

This guarantee is valid in the UK and Eire Only.

SPARE PARTS INFORMATION

Should you encounter problems, or require a replacement part, please consult the table below and then contact our Customer Services Department on:

+44 (0)844 984 0055.

CODE	DESCRIPTION
TS4036	Silicone Battery Cover
TS4037	Set of 2 Carbon Filter Replacements
TS4038BLK	Black Ozone Bin Lid
TS4038COP	Copper Ozone Bin Lid
TS4038GRY	Grey Ozone Bin Lid
TS4038SS	S/Steel Ozone Bin Lid
TS4038WHT	White Ozone Bin Lid

Your warranty becomes void should you decide to use non Tower spare parts.
The spare part is guaranteed for one year from the date of purchase.

Any necessary spare parts may also be purchased online from:

www.towerhousewares.co.uk

CUSTOMER SERVICES

Should you have a problem with your appliance, or need any spare parts, please call our Customer Services Department on: **+44 (0)844 984 0055**

It is important to retain the retailer's receipt as proof of purchase, and we suggest you staple it to this back cover for future reference.

Please make a note of the 60L Ozone Sensor Bin serial number and model number (you will find these on the box it came in).

Serial No. _____

Model No. _____



60 Litre Ozone Sensor Bin





TOWER®

BUILT FOR BETTER SINCE 1912

60 Litre Ozone Sensor Bin

thank you!

We hope you enjoy your product for many years. As a thank you for purchasing one of our fantastic products, we are giving you 5 years peace of mind.

To receive your 5 year guarantee, register your product online by visiting:

www.towerhousewares.co.uk

Should you have a problem or need any spare parts, please call our Customer Service Department on:

+44 (0)844 984 0055



great british design, innovation and excellence since 1912

Designed, developed and distributed throughout the UK by RKW Ltd.